



Turn your phone into a modem connection with a Laptop

1) To connect using USB cable

- Step 1: Connect the device to laptop via the **USB cable**.
- Step 2: Click on **Start**.
- Step 3: Select **Control Panel**.
- Step 4: Select **Phone and Modem Options**.
- Step 5: Select **Modems** Tab.
- Step 6: Select **Motorola USB Modem** and click on **Properties**.
- Step 7: Select **Diagnostics** Tab.
- Step 8: Click on **Query Modem**.
- Step 9: Select **Advanced** Tab.
- Step 10: Enter **at+cgdcont=1,"ip","unet"** into the **Extra initialization commands:** field.
- Step 11: Click **Ok** twice.
- Step 12: On the **Control Panel**, select **Network Connections**.
- Step 13: Select **Create a new connection** and click **Next**.
- Step 14: Select **Connect to the Internet** and click **Next**.
- Step 15: Select **Set up my connection manually** and click **Next**.
- Step 16: Select **Connect using a dial-up modem** and click **Next**.
- Step 17: Ensure that the **Modem – Motorola USB Modem** is **checked** and the rest unchecked and click **Next**.
- Step 18: Enter an **ISP Name** and click **Next**.
- Step 19: Enter ***99#** in the **Phone number:** field and click **Next**.
- Step 20: Select **My use only** and click **Next**.
- Step 21: Enter **maxis** into the **Username:** field.
- Step 22: Enter **wap** into the **Password:** field.
- Step 23: Ensure that all checked box are **Unchecked** and click **Next**.
- Step 24: Click **Finish**.
- Step 25: A pop-up will appeared, click **Dial** to connect.
- Step 26: Well Done! You have successfully connected as a modem.



2) To connect using Bluetooth

a) Setup on the Device

- Step 1: On the device, press **Menu**.
- Step 2: Scroll to **Connection** and press **Select**.
- Step 3: Scroll to **Bluetooth Link** and press **Select**.
- Step 4: Scroll to **Setup** and press **Select**.
- Step 5: Scroll to **Power** and press **Select**.
- Step 6: Scroll to **on** and press **Select**.

b) Setup on the Laptop

- Step 1: On the laptop, click on **Start**.



- Step 2: Select **Control Panel**.
- Step 3: Select and click on **Bluetooth Devices**.
- Step 4: Click on **Add..** and a pop-up “**Add Bluetooth Device Wizard**” would displayed.
- Step 5: Checked on “**My device is set up and ready to be found**” and press **Next**.
- Step 6: Select on **E1000 New device** and press **Next**.
- Step 7: Checked “Let me choose my own **passkey**” and enter an **8 to 16 digit passkey**.
- Step 8: Press **Next**.
- Step 9: On your device, “**Add to My Devices?**” is displayed, press **Yes**.
- Step 10: Enter the same 8 to 16 digit passkey that you have entered previously and press **Ok**.
- Step 11: Please wait while your laptop is installing the Bluetooth.
- Step 12: Press **Finish** when the Completing the “**Add Bluetooth Device Wizard**” is displayed.

c) Pairing of device via Bluetooth with the Laptop

- Step 1: Click on **Start**.
- Step 2: Select **Control Panel**.
- Step 3: Select **Phone and Modem Options**.
- Step 4: Select **Modems** Tab.
- Step 5: Select **Motorola USB Modem** and click on **Properties**.
- Step 6: Select **Diagnostics** Tab.
- Step 7: Click on **Query Modem**.
- Step 8: Select **Advanced** Tab.
- Step 9: Enter **at+cgdcont=1,"ip","unet"** into the **Extra initialization commands:** field.
- Step 10: Click **Ok** twice.
- Step 11: On the **Control Panel**, select **Network Connections**.
- Step 12: Select **Create a new connection**, follow through the Wizard.
- Step 13: Select **Connect to the Internet** and click **Next**.
- Step 14: Select **Set up my connection manually** and click **Next**.
- Step 15: Select **Connect using a dial-up modem** and click **Next**.
- Step 16: Ensure that the **Modem – Motorola USB Modem** is **checked** and the rest unchecked and click **Next**.
- Step 17: Enter an **ISP Name** and click **Next**.
- Step 18: Enter ***99#** in the **Phone number:** field and click **Next**.
- Step 19: Select **Anyone's use** and click **Next**.
- Step 20: Enter **maxis** into the **Username:** field.
- Step 21: Enter **wap** into the **Password:** field.
- Step 22: Ensure that all checked box are **Unchecked** and click **Next**.
- Step 23: Click **Finish**.
- Step 24: A pop-up will appeared and click **Dial** to connect.
- Step 25: Well Done! You have successfully connected as a modem.