

Turn your phone into a modem connection with a Laptop

1) To connect using USB cable

- Step 1: Install the software provided.
- Step 2: Follow through the instruction.
- Step 3: Select **Install Software**.
- Step 4: Select **Nokia PC Suite**.
- Step 5: Select **Nokia connectivity Cable driver**.
- Step 6: Exit from the Nokia 6680 software.
- Step 7: Connect your device to the laptop using the USB Cable.
- Step 8: Click on **Start**.
- Step 9: Scroll to and Select on **Control Panel**.
- Step 10: Scroll to **Phone and Modem Options**.
- Step 11: Choose **Modems** Tab.
- Step 12: Select **Nokia 6680 USB** and click on **Properties**.
- Step 13: Choose **Diagnostics** Tab.
- Step 14: Click on **Query Modem**.
- Step 15: Choose **Advanced** Tab.
- Step 16: Enter **at+cgdcont=1,"ip","unet"** into the **Extra initialization commands:** field.
- Step 17: Click **Ok** twice.
- Step 14: On the **Control Panel**, select **Network Connections**.
- Step 15: Select **Create a new connection** and click **Next**.
- Step 16: Select **Connect to the Internet** and click **Next**.
- Step 17: Select **Set up my connection manually** and click **Next**.
- Step 18: Select **Connect using a dial-up modem** and click **Next**.
- Step 19: Ensure that the **Modem – Nokia 6680 USB Modem** is **checked** and the rest unchecked and click **Next**.
- Step 20: Enter an **ISP Name** and click **Next**.
- Step 21: Enter ***99#** in the **Phone number:** field and click **Next**.
- Step 22: Select **My use only** and click **Next**.
- Step 23: Enter **maxis** into the **Username:** field.
- Step 24: Enter **wap** into the **Password:** field.
- Step 25: Ensure that all checked box are **Unchecked** and click **Next**.
- Step 26: Click **Finish**.
- Step 27: A pop-up will appeared, click **Dial** to connect.
- Step 28: Well Done! You have successfully connected as a modem.





2) To connect using Bluetooth

a) Setup on the Device

Step 1: On the device, press **Menu**.

Step 2: Scroll to **Connect**. and press the scroll key.

Step 3: Scroll to **Bluetooth** and press the scroll key.

Step 4: Scroll to **Bluetooth** and press the scroll key till **On** is displayed..

Step 5: Scroll to **My phone's visibility** and press the scroll key till **Shown to all** is displayed.

Step 6: Scroll to **My phone's name** and press the scroll key.

Step 7: Enter **Nokia 6680** in the field provided and press **Ok**.

Step 8: Press **Exit** and **End** key to go back to main screen.

b) Setup on the Laptop

Step 1: On the laptop, click on **Start**.

Step 2: Select **Control Panel**.

Step 3: Select and click on **Bluetooth Devices**.

Step 4: Click on **Add..** and a pop-up "**Add Bluetooth Device Wizard**" would displayed.

Step 5: Checked on "**My device is set up and ready to be found**" and press **Next**.

Step 6: Select on **Nokia 6680 New device** and press **Next**.

Step 7: Checked "Let me choose my own **passkey**" and enter an **8 to 16 digit passkey**.

Step 8: Press **Next**.

Step 9: On your device, "**Add to My Devices?**" is displayed, press **Yes**.

Step 10: Enter the same 8 to 16 digit passkey that you have entered previously and press **Ok**.

Step 11: Please wait while your laptop is installing the Bluetooth.

Step 12: Press **Finish** when the Completing the "**Add Bluetooth Device Wizard**" is displayed.

c) Pairing of device via Bluetooth with the Laptop

Step 1: Click on **Start**.

Step 2: Scroll to and Select on **Control Panel**.

Step 3: Scroll to **Phone and Modem Options**.

Step 4: Choose **Modems** Tab.

Step 5: Select **Nokia 6680 USB** and click on **Properties**.

Step 6: Choose **Diagnostics** Tab.

Step 7: Click on **Query Modem**.

Step 8: Choose **Advanced** Tab.

Step 9: Enter **at+cgdcont=1,"ip","unet"** into the **Extra initialization commands:** field.

Step 10: Click **Ok** twice.

Step 11: On the **Control Panel**, select **Network Connections**.

Step 12: Select **Create a new connection** and click **Next**.

Step 13: Select **Connect to the Internet** and click **Next**.



- Step 14: Select **Set up my connection manually** and click **Next**.
- Step 15: Select **Connect using a dial-up modem** and click **Next**.
- Step 16: Ensure that the **Modem – Nokia 6680 USB Modem** is **checked** and the rest unchecked and click **Next**.
- Step 17: Enter an **ISP Name** and click **Next**.
- Step 18: Enter ***99#** in the **Phone number:** field and click **Next**.
- Step 19: Select **My use only** and click **Next**.
- Step 20: Enter **maxis** into the **Username:** field.
- Step 21: Enter **wap** into the **Password:** field.
- Step 22: Ensure that all checked box are **Unchecked** and click **Next**.
- Step 23: Click **Finish**.
- Step 24: A pop-up will appeared, click **Dial** to connect.
- Step 25: Well Done! You have successfully connected as a modem.