

Turn your phone into a modem connection with a Laptop

1) To connect using USB cable

- Step 1: Connect the device to laptop via the **USB cable**.
- Step 2: A **Found New Hardware Wizard** would pop-up.
- Step 3: Follow through various wizard setups to install the drivers required.
- Step 4: Click on **Start**.
- Step 5: Select **Control Panel**.
- Step 6: Select **Phone and Modem Options**.
- Step 7: Select **Modems** Tab.
- Step 8: Select **Sony Ericsson Z800 USB WMC Modem** and click on **Properties**.
- Step 9: Select **Diagnostics** Tab.
- Step 10: Click on **Query Modem**.
- Step 11: Select **Advanced** Tab.
- Step 12: Enter **at+cgdcont=1,"ip","unet"** into the **Extra initialization commands:** field.
- Step 13: Click **Ok** twice.
- Step 14: On the **Control Panel**, select **Network Connections**.
- Step 15: Select **Create a new connection** and click **Next**.
- Step 16: Select **Connect to the Internet** and click **Next**.
- Step 17: Select **Set up my connection manually** and click **Next**.
- Step 18: Select **Connect using a dial-up modem** and click **Next**.
- Step 19: Ensure that the **Modem – Sony Ericsson Z800 USB WMC Modem** is **checked** and the rest **unchecked** and click **Next**.
- Step 20: Enter an **ISP Name** and click **Next**.
- Step 21: Enter ***99#** in the **Phone number:** field and click **Next**.
- Step 22: Select **My use only** and click **Next**.
- Step 23: Enter **maxis** into the **Username:** field.
- Step 24: Enter **wap** into the **Password:** field.
- Step 25: Ensure that all checked box are **Unchecked** and click **Next**.
- Step 26: Click **Finish**.
- Step 27: A pop-up will appeared, click **Dial** to connect.
- Step 28: Well Done! You have successfully connected as a modem.



2) To connect using Bluetooth

a) Setup on the Device

- Step 1: On the device, press **Menu**.
- Step 2: Scroll to **Settings** and press **Select**.
- Step 3: Scroll to **Connectivity** tab.
- Step 4: Scroll to **Bluetooth** and press **Select**.
- Step 5: Scroll to **Turn on** and press **Select**.

b) Setup on the Laptop



- Step 1: On the laptop, click on **Start**.
- Step 2: Select **Control Panel**.
- Step 3: Select and click on **Bluetooth Devices**.
- Step 4: Click on **Add..** and a pop-up “**Add Bluetooth Device Wizard**” would displayed.
- Step 5: Checked on “**My device is set up and ready to be found**” and press **Next**.
- Step 6: Select on **Z800 New device** and press **Next**.
- Step 7: Checked “**Let me choose my own passkey**” and enter an **8 to 16 digit passkey**.
- Step 8: Press **Next**.
- Step 9: On your device, “**Add to My Devices?**” is displayed, press **Yes**.
- Step 10: Enter the same 8 to 16 digit passkey that you have entered previously and press **Ok**.
- Step 11: Please wait while your laptop is installing the Bluetooth.
- Step 12: Press **Finish** when the Completing the “**Add Bluetooth Device Wizard**” is displayed.

c) Pairing of device via Bluetooth with the Laptop

- Step 1: Click on **Start**.
- Step 2: Select **Control Panel**.
- Step 3: Select **Phone and Modem Options**.
- Step 4: Select **Modems** Tab.
- Step 5: Select **Sony Ericsson Z800 USB WMC Modem** and click on **Properties**.
- Step 6: Select **Diagnostics** Tab.
- Step 7: Click on **Query Modem**.
- Step 8: Select **Advanced** Tab.
- Step 9: Enter **at+cgdcont=1,"ip","unet"** into the **Extra initialization commands:** field.
- Step 10: Click **Ok** twice.
- Step 11: On the **Control Panel**, select **Network Connections**.
- Step 12: Select **Create a new connection** and click **Next**.
- Step 13 Select **Connect to the Internet** and click **Next**.
- Step 14: Select **Set up my connection manually** and click **Next**.
- Step 15: Select **Connect using a dial-up modem** and click **Next**.
- Step 16: Ensure that the **Modem – Sony Ericsson Z800 USB WMC Modem** is **checked** and the rest **unchecked** and click **Next**.
- Step 17: Enter an **ISP Name** and click **Next**.
- Step 18: Enter ***99#** in the **Phone number:** field and click **Next**.
- Step 19: Select **My use only** and click **Next**.
- Step 20: Enter **maxis** into the **Username:** field.
- Step 21: Enter **wap** into the **Password:** field.
- Step 22: Ensure that all checked box are **Unchecked** and click **Next**.
- Step 23: Click **Finish**.
- Step 24: A pop-up will appeared, click **Dial** to connect.
- Step 25: Well Done! You have successfully connected as a modem.